
TR37E-SV & TR39E-SV (4S & 8M SERIAL



1. Handgrip- TRHG
2. Back Upholstery 17"- STDS2349BLK
   Back Upholstery 19"- STDS2351BLK
3. Push Handle Silver Vein- STDS4S3601
4. Back Uphol. Screws (8 ea)- STDS5D5504
5. Release Lever- STDS4S1503
6. Seat Rail Guide- STDS1070
7. Wheel Lock Left- STDS4S092L
   Wheel Lock Right- STDS4S092R
   Wheel Lock Tip- STDS4011
8. Tipping Sleeve- STDS4020
9. Rear Wheel Bearing- STDS4S3602
10. Hub Cap- STDS4S3603
11. Rear Axle- STDS4S3604
12. Rear Wheel- STDS4S3605
13. Axle Cap- STDS001000
14. Caster Bearing- STDS1011
15. Caster Axle- STDS1002-1
16. Caster- STDS3J2432
17. Fork- STDS3J4533
18. Fork Stem Bearing- STDS8M4601
19. Hanger pins (4 ea)- STDS5D1069
20. Seat Upholstery 17"- STDS2348BLK
    Seat Upholstery 19"- PL-STDS2350BLK
21. Seat Uphol. Screws (8 ea)- STDS1072-8
22. Dust Cap- STDS4S3606
23. Arm Pad- STDSFLVB
24. Arm Pad Screw- STDS002001
25. Axle Spacer- STDS3J0951
26. Footrest (pr)- TR39SF-SV
27. Seat Belt- STDS850-PB