

Linx



- | | |
|--|--|
| 1. Handgrip- STDS29SK5-02 | 19. Caster Bearing- STDS1011 |
| 2. Back Cane- STDS29SK5-01 | 20. Rear Wheel & Hand Rim- STDS29SK5-18 |
| 3. Back Ht Adj Knob (pr)- STDS29SK5-23 | 21. Hand Rim & Hardware- STDS29SK5-25 |
| 4. 16" Back Upholstery - STDS29SK5-03 | 22. Quick Release Axle - STDS29SK5-19 |
| 4. 18" Back Upholstery- STDS29SK5-04 | 23. Axle Receiver Assy- STDS29SK5-20 |
| 4. 20" Back Upholstery- STDS29SK5-05 | 24. Rear Wheel Bearing- STDS1060 |
| 5. Desk Arm Pad- STDS29SK5-06 | 25. Footrest - STDS29SK5-13 |
| 6. Ht Adj Arm Left- STDS29SK5-09 | 26. Footrest Bumper- STDS29SK5-26 |
| 6. Ht Adj Arm Right- STDS29SK5-08 | 27. Heel Loop (pr)- STDS29SK5-24 |
| 7. Upper Armrest - STDS29SK5-42 | 28. 16" Cross Frame- STDS29SK5-27 |
| 8. Ht Adj Armrest Button- STDS29SK5-43 | 28. 18" Cross Frame- STDS29SK5-28 |
| 9. Rear Armrest Receiver- STDS29SK5-07 | 28. 20" Cross Frame- STDS29SK5-29 |
| 10. Armrest Saddle Right- STDS29SK5-37 | 29. 16" Cross Frame Assist- STDS29SK5-33 |
| 10. Armrest Saddle Left- STDS29SK5-38 | 29. 18" Cross Frame Assist- STDS29SK5-34 |
| 11. 16" Seat Upholstery - STDS29SK5-10 | 29. 20" Cross Frame Assist- STDS29SK5-35 |
| 11. 18" Seat Upholstery - STDS29SK5-11 | 30. Side Frame, Right - STDS29SK5-30 |
| 11. 20" Seat Upholstery - STDS29SK5-12 | 30. Side Frame, Left, - STDS29SK5-31 |
| 12. Seat Belt - STDS29SK5-21 | 31. Left Brake- STDS29SK5-39 |
| 13. Rear Seat Saddle- STDS29SK5-36 | 31. Right Brake- STDS29SK5-40 |
| 14. Fork- STDS29SK5-16 | 32. Brake Tip- STDS29SK5-41 |
| 15. Dust Cap- STDS29SK5-32 | Brake Extension (ea)- STDS801GT |
| 16. Fork Stem Bearing (pr)- STDS29SK5-14 | 33. Anti-Tippers (pr)- STDS29SK5-22 |
| 17. Caster- STDS29SK5-17 | Not Shown- ELR (pr)- STDS29SK5-ELR |
| 18. Caster Axle- STDS29SK5-15 | |