
RTL10261 & RTL10261BC (5W-2M-15J SERIAL #)



1. Left Handgrip- 950340089901
   Right Handgrip- 950340079901
2. Hand Brake & Cable 5W-15J S/N- 9505W1026101
   Hand Brake & Cable 2M Serial #- 10216-01
3. Anti-Rattler (pr)- 950300169901
4. Height Adj. Knob (pr)- 9505W1026102
5. Folding Hinge Assy.- 9505W1026105
6. Rear Leg & Axle Sleeve Left - 9505W1026107
   Rear Leg & Axle Sleeve Right - 9505W1026106
7. Wheel Lock Left- 9505W1026109
   Wheel Lock Right- 9505W1026108
8. Rear Axle- 9505W1026111

Does

9b. Spring- 951021820000
9c. Cable Fastener- 9500004101
10. Rear Wheel 5W-15J Serial #- 9505W1026110
    Rear Wheel 2M Serial # [3]
11. Caster Axle- 9505W1026113
12. Rear Wheel Bearing- STDS1011
14. Seat with Brackets 5W-2M S/N- 9505W1026103
    Seat with Brackets 15J S/N- 9515J1026103 [2]

14a. Seat Hinge Brackets (pr)- 9505W1026104
15. Fork Stem Bearing- STDS1060
16. Left Front Leg Tube Only [1] - 9505W1026115
    Right Front Leg Tube only [1] - 9505W1026116
    Push Pin (4 each)- 9505W1026123
    End Plug (4 each)- 9505W1026122
17. Caster 5W Serial #- 9505W1026112
    Caster 15J Serial #- 9515J1026112
    Caster 2M Serial #- 9502M773412
18. Backrest Brkt. 5W-15J Serial #- 9505W1026121
    Backrest Pivot Brkt. 2M Serial #- 9501S72603
19. Backrest- 9505W1026117
20. Left Handlebar- 9505W1026118
    Right Handlebar- 9505W1026119
21. Tote- 9505W1026120
22. Dust Cap- STDS1051
23. Axle Cap- STDS001000
24. Front Leg Assembly Left- 9505W1026124
    Front Leg Assembly Right- 9505W1026125
25. Caster Bearing 5W-2M Serial #- STDS1011
    Caster Bearing 15J Serial #- 1992M-19

[1] Does not include push pin or end plug.
[2] 15J Serial # Does not have seat pouch.
[3] The part is no longer available.